

WM/SERIES WOOD MOULDING PATTERNS

6 Finish carpentry
Wood moulding and trim




WOOD MOULDING PATTERNS

Table of Contents

Astragal, Flat	4
Astragal, T	13
Back Bands	7
Base Caps	5
Base Mouldings	10
Base Shoes	4
Battens	6
Bed Mouldings	3
Brick Mouldings	5
Casing	8,9
Chair Rails	7
Chamfer Strips	12
Corner Guards	5
Cove Mouldings	3
Crown Mouldings	2
Drip Caps	5
Glass Beads	4
Half Rounds	4
Hand Rails	6
Inside Corner	12
Lattice	7
Mullion Casing	12
Panel Mouldings	5
Panel Strips	12
Picture Mouldings	7
Ply Cap Mouldings	7
Quarter Rounds	4
Rounds	6
S4S Stock	6
Screen Mouldings	4
Shelf Cleat	12
Shelf Edge	4
Screen Stock	6
Shingle Mouldings	6
Stools	12,13
Stops	11
Squares	6
Wainscot Mouldings	7
Moulding Weights	14
General Requirements	15
MDF General Requirements	16
How to "Build Up" Wood Mouldings to Create Larger Profiles	17
Consumer Wood Moulding Literature	19
Industry Literature and Merchandising Aids	19
Audio Visual Programs	20
Order Form	20
Bundling & Conversion Tables	21
Environmental Policy	Back Cover
Free Trade Policy	Back Cover

Quantities specified under each profile number
& dimension denotes pieces per bundle.

When you **purchase**
wood mouldings & millwork
ask for the **WMM** symbol of quality,
and when you **sell**
wood mouldings & millwork,
promote the **WMM** symbol of quality.



Member manufacturers of the
WOOD MOULDING & MILLWORK PRODUCERS ASSOCIATION

- Always manufacture to the industry's highest standards.
- Produce from renewable resources.
- Make optimum use of material, providing less waste of resources.
- Endorse national consumer advertising and public relations programs.
- Reinforce national marketing support and sales aids.

For further information or a complete WMMPA membership listing, write to:

WOOD MOULDING & MILLWORK PRODUCERS ASSOCIATION

507 FIRST STREET, WOODLAND, CA 95695-4025

PHONE: (530) 661-9591 FAX: (530) 661-9586

TOLL FREE: (800) 550-7889

WEB SITE: <http://wmmpa.com>



While the mouldings depicted in this book are standard profiles in the industry, all pattern numbers will not be available in your local market. Check with your local retailers or home centers to determine which profiles are commonly sold in your area.

WM / SERIES WOOD MOULDING PATTERNS

Wood mouldings have been an important architectural element since the first days of America to the present time. In colonial America, mouldings were most often produced at the construction site by joiners using hand planes. Many of the original designs and profiles have been retained in the standard mouldings produced by modern moulding plants. Today, with the producer and the market at times thousands of miles apart, a means of communication is needed to identify profiles. To promote the greatest efficiencies of mass production,

standardization also becomes necessary. Pattern books, using a variety of numbering systems, have been used to identify mouldings since the late 1800's. Because of changing lumber sizes and design preferences, an updating of catalogs are periodically required to reflect current industry practices. The Wood Moulding Patterns (WM/Series) is an updating that uses the basic numbering system of the former WP/Series. The profiles and sizes shown are those that reflect the most popular wood mouldings produced at the present time.

WOOD MOULDING & MILLWORK PRODUCERS ASSOCIATION

507 FIRST STREET, WOODLAND, CA 95695-4025
PHONE: (530) 661-9591 FAX: (530) 661-9586
TOLL FREE: (800) 550-7889
WEB SITE: <http://wmmpa.com>




Ricardo Terezan P. B. Tavares
Eng.º Produção - Materiais


WM 45
11/16 X 5-1/4
8 pcs.



WM 47
11/16 x 4-5/8
8 pcs.




WM 48
11/16 x 4-1/4
8 pcs.



WM 49
11/16 x 3-5/8
8 pcs.




WM 51
11/16 x 3-1/4
10 pcs.



WM 52
9/16 x 2-3/4
12 pcs.



WM 53
9/16 x 2-5/8
12 pcs.



WM 54
9/16 x 2-1/4
12 pcs.



WM 57
9/16 x 3-1/4
10 pcs.



CROWNS



WM 58
9/16 x 2-3/4
12 pcs.




WM 59
9/16 x 2-1/4
12 pcs.



WM 60
9/16 x 1-3/4
20 pcs.






WM 67
9/16 x 2-1/4
12 pcs.
















WM 68
9/16 x 1-5/8
20 pcs.




BEDS




COVES




QUARTER ROUNDS




May be used as a Base Shoe, Inside Corner Moulding, or to cover any 90° recessed juncture.




WM 103
1-1/16 x 1-1/16
20 pcs.




WM 104
11/16 x 1-3/8
25 pcs.




WM 105
3/4 x 3/4
40 pcs.



WM 106
11/16 x 11/16
40 pcs.



WM 107
5/8 x 5/8
40 pcs.



WM 108
1/2 x 1/2
50 pcs.




WM 109
3/8 x 3/8
50 pcs.




WM 110
1/4 x 1/4
50 pcs.

HALF ROUNDS



May be used as a Screen Moulding or Bead Shelf Edge or Panel Moulding.



WM 120
1/2 x 1
40 pcs.



WM 122
3/8 x 11/8
50 pcs.




WM 123
5/16 x 5/8
50 pcs.



WM 124
1/4 x 1/2
50 pcs.

BASE SHOES



Applied where Base Moulding meets floor. Protects Base from damage. Conceals uneven lines or cracks where Base meets floor.




WM 126
1/2 x 3/4
50 pcs.



WM 127
7/16 x 3/4
50 pcs.




WM 129
7/16 x 11/16
50 pcs.




WM 131
1/2 x 3/4
50 pcs.


FLAT ASTRAGALS




Attached to one of a pair of doors to keep the other from swinging through the opening. Also used for decorative purposes.



WM 133
11/16 x 1-3/4
20 pcs.




WM 134
11/16 x 1-3/8
25 pcs.




WM 135
7/16 x 3/4
50 pcs.

SHELF EDGE/SCREEN MOULDING



Covers seam where screening is fastened to the screen frame.



Also covers particle or flakeboard shelf edges.



WM 137
3/8 x 3/4 50 pcs.




WM 138
5/16 x 5/8 50 pcs.



WM 140
1/4 x 3/4 50 pcs.



WM 141
1/4 x 5/8 50 pcs.




WM 142
1/4 x 3/4 50 pcs.



WM 144
1/4 x 3/4 50 pcs.

GLASS BEADS



Used to hold glass in place. Also called Glass Stop, Cove & Bead, Putty Bead, Glazing Bead and Staff Bead.





WM 147
1/2 x 9/16
50 pcs.




WM 140
3/8 x 3/8
50 pcs.

BASE CAPS


A decorative member installed flush against wall and the top of an S4S Baseboard. Also a versatile Panel Moulding.




WM 163
11/16 x 1-3/8
25 pcs.




WM 164
11/16 x 1-1/8
30 pcs.



WM 166
11/16 x 1-1/4
30 pcs.




WM 167
11/16 x 1-1/8
30 pcs.



WM 172
5/8 x 3/4
40 pcs.


BRICK MOULD




Used as an exterior door & window Casing. A thick Moulding providing a surface for brick or other siding to butt against.



WM 175 1-1/16 x 2
8 pcs.




WM 176
1-1/16 x 1-3/4
12 pcs.




WM 180 1-1/4 x 2 8 pcs.


PANEL MOULDINGS




Originally used to trim out raised panel wall construction. Now, often used to frame attractive wall coverings for a paneled effect.



WM 182
11/16 x 1-5/8
20 pcs.



WM 183
9/16 x 1-1/8
40 pcs.




WM 186
3/8 x 1
40 pcs.




WM 185
9/32 x 1-3/8
40 pcs.


DRIP CAPS



Applied over exterior window & door frames. Keeps water from seeping under the siding. Also directs water away from window glass.



WM 187 1-1/16 x 2
12 pcs.



WM 188
1-1/16 x 1-5/8
12 pcs.




WM 196
11/16 x 1-3/4
20 pcs.




WM 197
11/16 x 1-5/8
20 pcs.


CORNER GUARDS



Outside (OS) Corner Guard is used to protect corners or to cover ragged edge where wall covering and painted surfaces meet at outside corner. (See page 12 for Inside Corner Guard.)




WM 199
1 x 1
20 pcs.




WM 200
3/4 x 3/4
40 pcs.



WM 201
1-5/16 x 1-5/16
20 pcs.



WM 202
1-1/8 x 1-1/8
20 pcs.



WM 204
1-5/16 x 1-5/16
20 pcs.











WM 205
1-1/8 x 1-1/8
20 pcs.





WM 206
3/4 x 3/4
40 pcs.


SHINGLE/PANEL MOULDINGS





BATTENS



HAND RAIL




ROUNDS




SQUARES



SCREEN/S4S STOCK




Same basic uses as Squares.



S4S stock also available in 7/16", 1/2", 9/16", 5/8" and 11/16" standard thickness.

LATTICE



Originally used in trellis work. This small, plain S4S Moulding is among the most versatile of profiles.

WM 265
9/32 x 1-3/4
30 pcs.

WM 266
9/32 x 1-5/8
30 pcs.


Lattice also available in 1/4 thickness.

WM 267
9/32 x 1-3/8
40 pcs.


WM 268
9/32 x 1-1/8
40 pcs.

WM 269
9/32 x 1-1/2
40 pcs.


PICTURE MOULDING



Used to support hooks for picture hanging. Applied around a room's circumference near the ceiling line.




WM 273
11/16 x 1-3/4
20 pcs.




WM 276
11/16 x 1-3/4
20 pcs.

BACK BANDS



A rabbeted Moulding used to surround the outside edge of Casing.



WM 280
11/16 x 1-1/16
30 pcs.



WM 281
11/16 x 1-1/8
30 pcs.


WAINSCOT/PLY CAP



Trims out the upper edge or top of a Wainscot. Covers plywood's rough sandwich edge in installations where it's exposed to view. Also called a Dado Cap.




WM 290
11/16 x 1-3/8
25 pcs.



WM 292
9/16 x 1-1/8
40 pcs.



WM 294
11/16 x 1-1/8
30 pcs.




WM 295
1/2 x 1-1/4
30 pcs.



WM 296
3/4 x 3/4
40 pcs.


CHAIR RAILS




Interior Moulding applied about one third up from the floor, paralleling Base Moulding and encircling the room. Originally used to prevent chairs from marring walls. Used today as a key decorative detail in traditional & colonial design.



WM 297
11/16 x 3
10 pcs.




WM 298
11/16 x 2-1/2
12 pcs.




WM 300
1-1/16 x 3
6 pcs.



WM 303
9/16 x 2-1/2
12 pcs.




WM 304
1/2 x 2-1/4
12 pcs.




WM 390
11/16 x 2-5/8
12 pcs.


CASING




WM 315
11/16 x 2-1/2
12 pcs.




WM 316
11/16 x 2-1/4
12 pcs.




WM 321
11/16 x 2-1/4
12 pcs.




WM 324
11/16 x 2-1/4
12 pcs.




WM 327
11/16 x 2-1/4
12 pcs.



WM 328
11/16 x 2-1/4
12 pcs.




WM 329
11/16 x 2-1/4
12 pcs.




WM 332
11/16 x 2-1/4
12 pcs.




WM 346
5/8 x 2-1/4
12 pcs.




WM 351
11/16 x 2-1/2
12 pcs.



WM 356
11/16 x 2-1/4
12 pcs.




WM 361
11/16 x 2-1/2
12 pcs.



WM 366
11/16 x 2-1/4
12 pcs.




WM 371
11/16 x 2-1/2
12 pcs.




WM 376
11/16 x 2-1/4
12 pcs.




WM 307
5/8 x 2-1/4
12 pcs.




WM 390
11/16 x 2-5/8
12 pcs.




WM 440
11/16 x 2-1/2
12 pcs.




WM 442
11/16 x 2-1/4
12 pcs.




WM 444
11/16 x 3-1/2
10 pcs.




WM 445
11/16 x 3-1/4
10 pcs.




WM 448
11/16 x 3-1/2
10 pcs.




WM 683
5/8 x 3-1/4 10 pcs.



WM 410 11/16 x 4-1/4 8 pcs.
WM 412 11/16 x 3-1/2 10 pcs.
WM 413 11/16 x 3-1/4 (Illus.) 10 pcs.



WM 430 9/16 x 4-1/4 8 pcs.
WM 432 9/16 x 3-1/2 10 pcs.
WM 433 9/16 x 3-1/4 (Illus.) 10 pcs.




WM 452 11/16 x 2-1/2 (Illus.) 12 pcs.
WM 453 11/16 x 2-1/4 12 pcs.




WM 472 9/16 x 2-1/2 (Illus.) 12 pcs.
WM 473 9/16 x 2-1/4 12 pcs.




WM 492 7/16 x 2-1/2 (Illus.) 20 pcs.
WM 493 7/16 x 2-1/4 20 pcs.




WM 503
1 x 3-1/2
6 pcs.




WM 520
1-1/16 x 3-1/2
6 pcs.




WM 523
1-1/16 x 3-1/2
6 pcs.



- WM 618** 9/16 x 5-1/4 8 pcs. **WM 632** 1/2 x 3-1/2 10 pcs.
WM 620 9/16 x 4-1/4 8 pcs. **WM 633** 1/2 x 3-1/4 10 pcs.
WM 622 9/16 x 3-1/2 10 pcs. (illus.)
WM 623 9/16 x 3-1/4 10 pcs. **WM 634** 1/2 x 3 10 pcs.
 (illus.)
WM 624 9/16 x 3 10 pcs.



- WM 709** 9/16 x 4-1/2 8 pcs. **WM 722** 1/2 x 3-1/2 10 pcs.
WM 710 9/16 x 4-1/4 8 pcs. **WM 723** 1/2 x 3-1/4 10 pcs.
WM 712 9/16 x 3-1/2 10 pcs. (illus.)
WM 713 9/16 x 3-1/4 10 pcs. **WM 724** 1/2 x 3 10 pcs.
 (illus.) **WM 725** 1/2 x 2-1/2 12 pcs.
WM 714 9/16 x 3 10 pcs. **WM 726** 1/2 x 2-1/4 12 pcs.




- WM 658** 9/16 x 5-1/4 8 pcs. **WM 750** 9/16 x 4-1/4 8 pcs.
WM 660 9/16 x 4-1/4 8 pcs. **WM 752** 9/16 x 3-1/2 10 pcs.
WM 662 9/16 x 3-1/2 10 pcs. **WM 753** 9/16 x 3-1/4 10 pcs.
WM 663 9/16 x 3-1/4 10 pcs. (illus.)
WM 664 9/16 x 3 10 pcs.



- WM 738**
 9/16 x 5-1/4
 8 pcs.

BASE MOULDINGS



Applied where floor & walls meet, forming a visual foundation. Protects walls from kicks, bumps, furniture, etc. Base may be referred to as One, Two or Three-Member. Base Shoe & Base Cap are used to conceal uneven floor & wall junctions.

STOPS



In door trim, Stop is nailed to the faces of the door frame to prevent the door from swinging through. As window trim, Stop holds the bottom sash of a double-hung window in place. Also used as an apron under window stools.



- WM 813 7/16 x 2-1/4 20 pcs.
- WM 814 7/16 x 1-3/4 30 pcs.
- WM 815 7/16 x 1-5/8 30 pcs.
- WM 816 7/16 x 1-3/8 (Illus.) 30 pcs.
- WM 817 7/16 x 1-1/4 30 pcs.
- WM 818 7/16 x 1-1/8 40 pcs.
- WM 820 7/16 x 7/8 50 pcs.



- WM 823 3/8 x 2-1/4 20 pcs.
- WM 824 3/8 x 1-3/4 30 pcs.
- WM 825 3/8 x 1-5/8 30 pcs.
- WM 826 3/8 x 1-3/8 (Illus.) 30 pcs.
- WM 827 3/8 x 1-1/4 30 pcs.
- WM 828 3/8 x 1-1/8 40 pcs.
- WM 830 3/8 x 7/8 50 pcs.
- WM 831 3/8 x 3/4 50 pcs.



- WM 843 7/16 x 2-1/4 20 pcs.
- WM 844 7/16 x 1-3/4 30 pcs.
- WM 845 7/16 x 1-5/8 30 pcs.
- WM 846 7/16 x 1-3/8 (Illus.) 30 pcs.
- WM 847 7/16 x 1-1/4 30 pcs.
- WM 848 7/16 x 1-1/8 40 pcs.
- WM 850 7/16 x 7/8 50 pcs.
- WM 851 7/16 x 3/4 50 pcs.




- WM 853 3/8 x 2-1/4 20 pcs.
- WM 854 3/8 x 1-3/4 30 pcs.
- WM 855 3/8 x 1-5/8 30 pcs.
- WM 856 3/8 x 1-3/8 (Illus.) 30 pcs.
- WM 857 3/8 x 1-1/4 30 pcs.
- WM 858 3/8 x 1-1/8 40 pcs.
- WM 860 3/8 x 7/8 50 pcs.
- WM 861 3/8 x 3/4 50 pcs.



- WM 873 7/16 x 2-1/4 20 pcs.
- WM 874 7/16 x 1-3/4 30 pcs.
- WM 875 7/16 x 1-5/8 30 pcs.
- WM 876 7/16 x 1-3/8 (Illus.) 30 pcs.
- WM 877 7/16 x 1-1/4 30 pcs.
- WM 878 7/16 x 1-1/8 40 pcs.
- WM 880 7/16 x 7/8 50 pcs.
- WM 881 7/16 x 3/4 50 pcs.




- WM 883 3/8 x 2-1/4 20 pcs.
- WM 884 3/8 x 1-3/4 30 pcs.
- WM 885 3/8 x 1-5/8 30 pcs.
- WM 886 3/8 x 1-3/8 (Illus.) 30 pcs.
- WM 887 3/8 x 1-1/4 30 pcs.
- WM 888 3/8 x 1-1/8 40 pcs.
- WM 890 3/8 x 7/8 50 pcs.
- WM 891 3/8 x 3/4 50 pcs.




- WM 903 7/16 x 2-1/4 20 pcs.
- WM 904 7/16 x 1-3/4 30 pcs.
- WM 905 7/16 x 1-5/8 30 pcs.
- WM 906 7/16 x 1-3/8 (Illus.) 30 pcs.
- WM 907 7/16 x 1-1/4 30 pcs.
- WM 908 7/16 x 1-1/8 40 pcs.
- WM 910 7/16 x 7/8 50 pcs.
- WM 911 7/16 x 3/4 50 pcs.



- WM 913 3/8 x 2-1/4 20 pcs.
- WM 914 3/8 x 1-3/4 30 pcs.
- WM 915 3/8 x 1-5/8 30 pcs.
- WM 916 3/8 x 1-3/8 (Illus.) 30 pcs.
- WM 917 3/8 x 1-1/4 30 pcs.
- WM 918 3/8 x 1-1/8 40 pcs.
- WM 920 3/8 x 7/8 50 pcs.
- WM 921 3/8 x 3/4 50 pcs.




- WM 933 7/16 x 2-1/4 20 pcs.
- WM 934 7/16 x 1-3/4 30 pcs.
- WM 935 7/16 x 1-5/8 30 pcs.
- WM 936 7/16 x 1-3/8 (Illus.) 30 pcs.
- WM 937 7/16 x 1-1/4 30 pcs.
- WM 938 7/16 x 1-1/8 40 pcs.
- WM 940 7/16 x 7/8 50 pcs.
- WM 941 7/16 x 3/4 50 pcs.



- WM 943 3/8 x 2-1/4 20 pcs.
- WM 944 3/8 x 1-3/4 30 pcs.
- WM 945 3/8 x 1-5/8 30 pcs.
- WM 946 3/8 x 1-3/8 (Illus.) 30 pcs.
- WM 947 3/8 x 1-1/4 30 pcs.
- WM 948 3/8 x 1-1/8 40 pcs.
- WM 950 3/8 x 7/8 50 pcs.
- WM 951 3/8 x 3/4 50 pcs.



- WM 953 7/16 x Width Specified



- WM 954 3/8 x Width Specified

PANEL STRIPS/MULLION CASINGS



The strip which is applied over window jamb edges in a multiple opening window. Sometimes called a Panel Strip. Also used for decorative wall treatments.



WM 955 3/8 x 2-1/4 20 pcs.
WM 956 3/8 x 2 20 pcs.
WM 957 3/8 x 1-3/4 30 pcs.



WM 960 3/8 x 2-1/4 20 pcs.
WM 962 3/8 x 2 20 pcs.
WM 963 3/8 x 1-3/4 30 pcs.



WM 965 3/8 x 2-1/4 20 pcs.
WM 967 3/8 x 2 20 pcs.
WM 968 3/8 x 1-3/4 30 pcs.



WM 970 3/8 x 2-1/4 20 pcs.
WM 972 3/8 x 2 20 pcs.
WM 973 3/8 x 1-3/4 30 pcs.



WM 975 3/8 x 2-1/4 20 pcs.
WM 977 3/8 x 2 20 pcs.
WM 978 3/8 x 1-3/4 30 pcs.




WM 980 3/8 x 2-1/4 20 pcs.
WM 982 3/8 x 2 20 pcs.
WM 983 3/8 x 1-3/4 30 pcs.



WM 985 3/8 x 2-1/4 20 pcs.
WM 987 3/8 x 2 20 pcs.
WM 988 3/8 x 1-3/4 30 pcs.


SHELF CLEAT



Commonly used in closets, cabinets & bookcases to support the shelves. Also called Shelf Strip.




WM 990
 11/16 x 1-1/2
 25 pcs.




WM 995
 3/4 x 3/4
 50 pcs.

CHAMFER STRIP



Used in highway & dam construction forms, making a chamfered edge at concrete corners. Also used where kitchen cabinet tops meet the wall. Also used as a linoleum Cove, (under linoleum where it extends up the wall).


INSIDE CORNER




Joins two walls at inside corner. Solves problems of uneven joints where butted panels, wallpaper, painted or contrasting surfaces meet. Gives corners a decorative finished look.



WM 999
 5/16 x 1 50 pcs.




WM 1021
 11/16" x width specified




WM 1022
 11/16" x width specified

FLAT STOOLS





A moulded interior trim member serving as a sash or window-frame sill cap. Stools may be "beveled-rabbeted" or "rabbeted" to receive the window-frame sill or "non-rabbeted." Some "non-beveled" or "non-rabbeted" stools include a tongue to fit in the groove of the window-frame sill.

RABBETED STOOLS



A moulded interior trim member serving as a sash or window-frame sill cap.


SPECIFY WIDTH OF RABBET (W), DEGREE FOR BEVEL (B), RABBET FRONT DEPTH (FD), AND RABBET BACK DEPTH (BD).



WM 1131 1-1/16 x 3-5/8
6 pcs.

WM 1133 1-1/16 x 3-1/4
6 pcs.

WM 1134 1-1/16 x 2-3/4
6 pcs.




WM 1153 11/16 x 3-1/4
10 pcs.

WM 1154 11/16 x 2-3/4
12 pcs.

WM 1155 11/16 x 2-1/2
12 pcs.


WM 1156 11/16 x 2-1/4
12 pcs.



WM 1161 1-1/16 x 3-5/8
6 pcs.

WM 1163 1-1/16 x 3-1/4
6 pcs.

WM 1164 1-1/16 x 2-3/4
6 pcs.




WM 1193 11/16 x 3-1/4
10 pcs.

WM 1194 11/16 x 2-3/4
12 pcs.


WM 1195 11/16 x 2-1/2
12 pcs.

WM 1196 11/16 x 2-1/4
12 pcs.


T-ASTRAGALS




An Astragal, T-like in shape, which is rabbeted to the approximate thickness of the swinging door.




WM 1300
1-1/4 x 2-1/4
10 pcs.



WM 1305
1-1/4 x 2
10 pcs.



WM 1310
1-1/4 x 2-1/4
10 pcs.



WM 1315
1-1/4 x 2
10 pcs.

MOULDING WEIGHTS

ESTIMATED WEIGHT
PER 1000 LINEAL FEET
FOR LINEAL SASH,
S4S, ROUND EDGE
PATTERNS, ETC

WIDTH	THICKNESS											
	1/4	9/32	5/16	3/8	7/16	1/2	9/16	5/8	11/16	3/4	1-1/8	1-3/8
1/4	11	—	—	—	—	—	—	—	—	—	—	—
5/16	14	—	—	—	—	—	—	—	—	—	—	—
3/8	17	19	21	25	—	—	—	—	—	—	—	—
1/2	22	25	28	34	39	45	—	—	—	—	—	—
5/8	28	31	35	42	49	56	63	70	70	—	—	—
3/4	34	35	42	50	59	67	75	84	84	101	—	—
7/8	39	44	49	59	69	78	88	98	98	118	157	—
1	45	50	56	67	78	90	101	112	112	134	180	—
1-1/8	50	57	63	76	88	101	113	126	126	151	227	—
1-1/4	56	63	70	84	98	112	126	140	140	168	252	—
1-3/8	62	69	78	92	108	123	138	154	154	185	277	338
1-1/2	67	75	84	101	118	134	151	168	168	202	302	370
1-5/8	73	81	91	109	127	146	164	182	182	218	328	400
1-3/4	78	83	98	118	137	157	177	196	196	235	353	431
2	—	—	—	134	159	179	201	224	224	269	403	493
2-1/4	—	—	—	151	176	202	227	252	252	302	454	554
2-1/2	—	—	—	—	196	224	252	280	280	336	504	616
2-5/8	—	—	—	—	206	236	265	294	294	353	529	641
2-3/4	—	—	—	—	216	247	278	308	308	370	554	678
3	—	—	—	—	—	269	302	336	336	403	605	739
3-1/4	—	—	—	—	—	297	328	364	364	437	655	800
3-1/2	—	—	—	—	—	—	353	392	392	470	706	862
3-5/8	—	—	—	—	—	—	—	406	406	487	731	893
3-3/4	—	—	—	—	—	—	—	420	420	504	756	924
4-1/4	—	—	—	—	—	—	—	476	476	571	857	1047
4-3/4	—	—	—	—	—	—	—	532	532	638	958	1170
5-1/2	—	—	—	—	—	—	—	616	616	739	1008	1356
5-3/4	—	—	—	—	—	—	—	644	644	773	1159	1417

THE ESTIMATED
WEIGHTS ARE
FOR MOST WESTERN
SOFTWOODS EXCEPT
LARCH, DOUGLAS FIR,
SOUTHERN PINE AND
RADIATA PINE. FOR
THESE FOUR SPECIES
ADD 16% TO THE
WEIGHTS LISTED IN
THE CHART

THE ESTIMATED WEIGHT
PER 1000 LINEAL FEET
FOR MOULDED
PATTERNS

WIDTH	THICKNESS											
	1/4	9/32	5/16	3/8	7/16	1/2	9/16	5/8	11/16	3/4	1-1/8	1-3/8
1/4	9	—	—	—	—	—	—	—	—	—	—	—
5/16	12	—	—	—	—	—	—	—	—	—	—	—
3/8	14	16	17	21	—	—	—	—	—	—	—	—
1/2	19	21	23	28	33	37	—	—	—	—	—	—
5/8	23	26	29	35	41	47	53	59	59	—	—	—
3/4	28	32	35	42	49	56	63	70	70	84	—	—
7/8	33	37	41	49	57	66	74	82	82	98	—	—
1	37	42	47	56	66	75	83	94	94	112	—	—
1-1/8	42	47	53	63	74	84	95	105	105	126	190	—
1-1/4	47	53	59	70	82	94	106	117	117	140	211	—
1-3/8	52	58	64	77	90	103	116	129	129	154	232	283
1-1/2	56	63	70	84	98	112	126	140	140	169	253	309
1-5/8	61	68	76	91	104	122	137	152	152	183	274	335
1-3/4	66	74	82	98	117	131	147	164	164	197	295	360
2	—	—	—	112	131	150	169	187	187	225	337	412
2-1/4	—	—	—	126	148	169	211	211	211	253	379	463
2-1/2	—	—	—	—	164	187	222	234	234	281	421	515
2-5/8	—	—	—	—	170	197	231	246	246	295	442	541
2-3/4	—	—	—	—	180	206	252	257	257	309	463	566
3	—	—	—	—	—	—	274	281	281	337	505	618
3-1/4	—	—	—	—	—	—	—	304	304	365	548	669
3-1/2	—	—	—	—	—	—	—	328	328	393	590	721
3-5/8	—	—	—	—	—	—	—	339	339	407	611	750
3-3/4	—	—	—	—	—	—	—	351	351	421	632	772
4-1/4	—	—	—	—	—	—	—	374	374	477	716	875
4-3/4	—	—	—	—	—	—	—	445	445	534	800	978
5-1/2	—	—	—	—	—	—	—	515	515	618	927	1356
5-3/4	—	—	—	—	—	—	—	538	538	646	969	1420

ESTIMATED
WEIGHTS ARE
FOR MOST WESTERN
SOFTWOODS EXCEPT
LARCH, DOUGLAS FIR,
SOUTHERN PINE AND
RADIATA PINE. FOR
THESE FOUR SPECIES
ADD 16% TO THE
WEIGHTS LISTED IN
THE CHART